Xiamen Rizheng Industry Co.,Ltd


New Detachable Key Chain Kits Assembly Instructions

REQUIRED ACCESSORIES:

- 7mm, Pen Mandrel
- 7mm drill bit RZ-DB007
- 2-piece Bushing Set RZ-KR42#-BU
- 7mm barrel trimmer RZ-PM011
- Glue (Thick CA or Epoxy)




- Cut a 5/8" to 1" square blank or larger, depending on your design, to the length of the tube (add 1/16" for squaring off).
- Drill a 7mm center hole lengthwise through the blank.
- Spread glue over the tube, then insert it into the blank with a twisting motion to spread the glue evenly inside.
- Center the tube lengthwise inside the blank.
- When the glue dries, use a barrel trimmer, universal squaring jig, or a belt/disc sander to take the wood down, flush to the brass tube.



TURNING THE BLANK

- Mount the bushings and blanks according to diagram A.
- Thread on the knurled nut and hand tighten to hold all components in place. Slide the Tailstock up snugly against the Mandrel shaft, inserting the live center point into the Mandrel dimple. Lock Tailstock.
- Hand tighten the quill adjustment on the tailstock to steady the mandrel. Do not over tighten, it could damage the mandrel shaft.
- When using Mandrel Saver, there is no need for extra spacer bushings or the knurled nut. Slide tailstock directly against bushings and tighten until blank and bushings are secure.
- Using sharp tools, turn the blank down close to the bushing diameter. Turn the barrel straight or to a profile of your choice.
- Sand the blank down to be flush with the bushings, gradually increasing sandpaper grits. Finish the barrel using your choice of polish. Allow Sufficient time for the polish to cure—refer to polish instructions.



ASSEMBLY

- Line-up the parts according to the above picture.
- Unscrew the coupler from the bottom of both the new detach assembly and Swivel ends. Be sure not to lose the spring.
- Press the couplers into the tube, one side at a time.
- Spring can be put into the recess on either coupler before screwing the new detach assembly onto that coupler.
- Line-up the Swivel assembly parts and screw the Swivel assembly onto the other coupler.
- Attach one Key Ring into the hole in the Swivel.
- The other Key Ring can be inserted into the detach assembly by pushing down on the button and slipping it in while the detach assembly is open.
- Either key ring can be attached to loops, other key rings, or straps. Use the clip to attach and detach as needed.